
















ITEM NAME/NOM D'ITEM: ALLEN COUNTER CHAIR
ITEM #/NO.ITEM : 100956

PARTS LIST/LISTE DES PIÈCES


(1)	(2)	(5)
 x1	 x2	<p>A. JCBC SCREW M6 x 50MM x8 </p> <p>B. SPRING WASHER 1/4" x8 </p> <p>C. M4 ALLEN KEY (BALL SHAPE) LONG x1 </p>
(3A)	(4)	D. PAN HEAD WOOD SCREW 5 X 32MM x10 
 x1	 x2	E. WOOD DOWEL DIA 8 x 35MM x4 
(3B)		F. WOOD DOWEL DIA 8 x 25MM x2 
 x1		G. ADJUSTABLE SCREW x4 

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE


I.



II.



III.



IV.

