












ITEM NAME/ NOM D'ITEM: ALDEN DINING CHAIR
ITEM#/NO.ITEM: 100977

PART LIST / LISTE DES PIÈCES

(1)	(2)	(3)	(4)	(5)	EXTRA
 <p>R L</p> <p>x2</p>	 <p>x1</p>	 <p>x1</p>	 <p>x1</p>	<p>(A)  M6x70(RB) x4</p> <p>(B)  M6x20(BLK) x4</p> <p>(C)  Ø6mm x4</p> <p>(D)  x4</p> <p>(E)  M5X32 x8</p> <p>(F)  M6 x1</p>	<p>x1</p> <p>x1</p> <p>x1</p> <p>x1</p> <p>x1</p> <p>-</p>

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE



For missing parts or damaged parts, please call

USA : 1-866-798-6663

Canada : 514-382-6661

AI-1-180416