













ITEM NAME/ NOM D'ITEM: TIDAL DINING CHAIR
ITEM #/NO. ITEM: 703752/703753/703754

PARTS LIST/LISTE DES PIÈCES

(1)	(2)	(3)	(4)
 x1	 3+ 4+ x1	 x2	 x2
(5)			
A.  Ø6mm x4	B.  4mm x1	C.  M6 x 45mm x8	D.  M6 x 20mm x4
E.  10mm x1	F.  M6 x8	G.  Ø6mm x4	H.  Ø6mm x8

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE

I.

II.

III.

IV.

For missing parts or damaged parts, please call

USA : 1-866-798-6663
 Canada : 514-382-6661

AI-3-190221