







ITEM NAME/NOM D'ITEM: PISMO DINING CHAIR


ITEM # / NO. ITEM: 703843

PARTS LIST/LISTE DES PIÈCES


(1)	(3)	(4)
 <p>x1</p>	 <p>x1</p>	<p>A. x12 </p>
<p>(2)</p>		<p>B. x12 </p>
 <p>x4</p>		<p>C. x1 </p>

ASSEMBLY INSTRUCTIONS/INSTRUCTIONS D'ASSEMBLAGE

I



II



For missing parts or damaged parts, please call USA : 1-866-798-6663
Canada : 514-382-6661